


- Foam seal lips for VFB series vacuum cups
- Used for handling rough or embossed surfaces
- Self adhesive seal bonds to base of VFB series vacuum cups



FCR		30		S	
Series	Model	Suitable for Cup Model	Seal Material		
	20	VFB20	N	NBR	
	30	VFB30-2	S	Silicone	
	40	VFB40			
	50	VFB50-2			


ASSEMBLY



Ensure that the vacuum cup is free from dirt and grease on the sealing lip and is in good overall condition. Remove the self adhesive seal from the foam ring and place on a flat surface with sticky face upwards.

Place cup centrally over foam ring and press against the foam ring squarely and firmly for 1-2 seconds.

DIMENSIONS (mm)



For larger foam cups please refer to pages 1.30 and 1.31

